

NATURE DELUXE

QUICK FIT GUIDE:
PLANNING & INSTALLATION

ROLS



QUICK FIT GUIDE: PLANNING & INSTALLATION

You are considering the purchase of a beautiful high-quality carpet, but don't forget it needs a skilled installer to ensure its beauty is lasting. The best carpet installers are highly skilled, have great knowledge, will give excellent advice and take pride in their work. Always ensure your installer works to the national code of practice for carpet installation and selects the best materials and method of carpet laying for the individual project. We believe a site visit from your installer is an essential part of the process and that they should have seen samples of the materials you intend to install. In a number of key markets, we have both trade installation partners (business to business) and approved retail dealers (business to consumer) who will be happy to assist with your installation requirements. Please contact your territory manager for information on our installation partners. The following information is provided in good faith and no responsibility is accepted by Moquetas Rols for claims arising from any proposed installation methods.

Phase	Operation/description
A) Project Planning	A.1) Seaming/joining (Note 1) A.2) Multi width seaming (Note 3)
B) On site Preparation	B.1) Perimeter Gripper Type (Note 4) B.2) Gripper Banking B.3) Gripper Position (From Perimeter of room)
C) Carpet Preparation	C.1) Carpet/Seam Cutting (Note 6) C.2) Seam Sealing (cut edges) (Note 7) C.3) Seaming Method (Note 8)

Fitting Method

Double-Stick (Note 2)
Side-to-side only
No manufacturers selvedge
Short Pin Length
Single (Note 5)
3mm
Back Cut
Seam edges must be sealed
N/A

Note 1: The cutting and seaming together of a flatweave is a precise and time consuming process with the resulting join likely to be variable in appearance. The durability of seams cannot be guaranteed in multi-width installations. For this reason we do not recommend either side to side or end to end joins in our flatweave structures

Note 2: We do not recommend this carpet be stretch fitted. Carpet should be fully bonded to prepared sub floors, or installed using the Double-Stick method

Note 3: This carpet is manufactured with an open selvedge that must be trimmed back for seaming. Attention must be paid in both planning and seam execution, to the pattern match and weave structure on the edges of the carpet body, to ensure a consistent seam is achieved. Upon receipt of the carpet we recommend close inspection of both edges, as it will be necessary to cut back into the body of the carpet to achieve a uniform join and pattern match, which is consistent on both sides of the seam. We do not recommend that this carpet is cut through the last line of the protective open selvedge and butt joined

Note 4: This carpet should only be fitted on short pin length Blank Gripper

Note 5: Double stick installations will require the use of Blank Gripper which should be positioned 3 mm from the perimeter walls or skirting

Note 6: This carpet can only be cut from the back. Using a sharp knife, cut cleanly along the line of the warpwise row. Care must be taken to cut a straight line within the individual row and not to transgress to the rows on either side of the cut line

Note 7: Where edges are cut to create a seam, the cut edges must be sealed using a proprietary seam sealant. The sealant must be allowed sufficient time to dry before forming the seam. Darker colours will offer a better visual seam as they will disguise better with the backing

Note 8: We recommend the use of a quality seaming tape. Where possible the use of an electrically activated seaming tape (Silvaseam) is recommended as this allows greater control in the formation of the seam